


INSTALLATION LAYOUT FOR MODELS HSC-50 / HSC-100

INSTALLATION LAYOUT FOR DISHWASHERS

TO DISH WASHER PRESSURE HEATER ARRESTER DISPENSING HEAD SHUT OFF PRESSURE VALVE REDUCER TO APPLICATION TO WATER SUPPLY

INSTALLATION LAYOUT FOR COMMERCIAL USE



INSTALLATION INSTRUCTIONS

- Install a check valve after the water unit as required to prevent backflow.
- DO NOT remove end caps from the (replaceable) cartridge.
- DO DISCARD the orange moisture cap PRIOR to cartridge installation.
- Inlet and Outlet are 3/4" NPT (female)

UNIT MOUNTING INSTRUCTIONS

- 1. Mount the unit with the supplied bracket to a wall or a piece of equipment that can support the weight of the unit.
- 2. Mount the units' head horizontally with the sump below it. The unit will not function properly in any other orientation.
- 3. Connect the necessary plumbing (refer to diagram above). A check valve may be installed after the unit. Also, install a shut-off valve on the inlet side of the head and on the outlet side of the head to facilitate the removal of the sump for cartridge replacement.
- 4. Mount the unit out of direct sunlight and out of excessive or freezing temperatures.

NOTE: Periodically check the SCALTROL cartridge and use only genuine replacements
Replace the cartridge when the level of Scaltrol mixture reaches the bottom end cap.