



The Clear Choice in Water Treatment

REPLACEMENT CARTRIDGE INSTALLATION INSTRUCTIONS for SC-500

1. Shut off water flow to unit.
2. Release water pressure by opening a nearby valve/faucet.
3. Remove the entire sump/bowl with the wrench attached to the existing SC-500. Discard the entire sump; it is not re-used.
4. Remove the new RSC-500 sump from its packing material.

DO NOT DISCARD THE PLASTIC DISK ON TOP OF THE COMPOUND SHIPPED WITH THE NEW RSC-500.

5. Make sure that the black gasket is placed on the top flat flange of the sump (not on the side groove). Screw the RSC-500 sump onto the head unit.

6. Retighten the sump. **DO NOT OVERTIGHTEN.**

7. Slowly reopen the water shut off valve and let the unit fill. Once it is full, completely open the water supply valve.

8. Re-check for leaks.

NOTES:

Periodically check the SCALTROL unit and use ONLY genuine SCALTROL replacements.

Replace the cartridge/sump when the level of the SCALTROL mixture reaches the bottom of the sump.



*Scaltrol Inc. • 2410 Satellite Blvd., Suite M • Buford, GA 30518
Mailing address: P.O. Box 3288 • Suwanee, Georgia 30024
Phone: 800-868-0629 ext. 201 • Fax: 877-769-2751 • www.scaltrolinc.com*